

The Anywhere feature associates your mobile phone to your desk phone.

To activate Anywhere, your mobile phone number must be programmed by your administrator.

When the Anywhere is activated on your extension, all incoming calls will ring simultaneously on your desk phone and mobile phone.

** Ask your administrator to provide you with your Anywhere feature access phone number.*

To Deactivate the Anywhere feature

From your mobile phone or desk phone

Call your Anywhere number, enter the password of your VoiceMail followed by #. Then, enter *13.

You can add a contact in your mobile phone or program a speed dial on your telephone to facilitate the Deactivation of this service. Program this chain of digits:

YourAnywhereNumber , password # *13 #

Example: 5141234567 , 5894 # *13 #

From another phone

Call your Anywhere number. Enter the mobile phone associated with your extension, then enter the password of your VoiceMail followed by #. Then, enter *13.

You can program a speed dial on a telephone to facilitate the Deactivation of this service. Program this chain of digits:

YourAnywhereNumber , mobilephonenumber # password # *13 #

Example: 5141234567 , 5149876543 # 5894 # *13 #

To Activate the Anywhere feature

From your mobile phone or desk phone

Call your Anywhere number, enter the password of your VoiceMail followed by #. Then, enter *12.

You can add a contact in your mobile phone or program a speed dial on your telephone to facilitate the Activation of this service. Program this chain of digits:

YourAnywhereNumber , password # *12 #

Example: 5141234567 , 5894 # *12 #

From another phone

Call your Anywhere number. Enter the mobile phone associated with your extension, then enter the password of your VoiceMail followed by # key. Then, enter *12.

You can program a speed dial on a telephone to facilitate the Activation of this service. Program this chain of digits:

YourAnywhereNumber , mobilephonenumber # password # *12 #

Example: 5141234567 , 5149876543 # 5894 # *12 #

To pull/move a call from one phone to another

To pull/move a call from your desk phone to your mobile phone

On your mobile, dial your Anywhere number followed by the password of your VoiceMail and #, then press *11 and #.

Example: 5141234567 , 5894 # *11 #

The call will be moved transparently for the caller and the communication on your desk phone will be ended.

You can add a contact in your mobile phone to facilitate the use of this service. Program this chain of digits:

YourAnywhereNumber , password # *11 #

Example: 5141234567 , 5894 # *11 #

To pull/move a call from your mobile phone to your desk phone

On your desk phone, press the Anywhere key or dial *11 and #.

The call will be moved transparently for the caller and the communication on your mobile will be ended.

To transfert a call from your mobile phone

You can tranfert a call, that rang on your desk phone, that you answered from your mobile phone to any office internal extension or any public telephone number.

To transfert a call to an office internal extension

On your mobile phone, during the call, press ## followed by the extension number, then #.

Example: ##221# to transfert the call to the receptionniste.

The caller will be placed On Hold while the communication is established.

To transfert a call to a public telephone number

On your mobile phone, during the call, press ## followed by the public telephone number, then #.

Example: ##5144444742# to transfert the call to IP4B telecom.

The caller will be placed On Hold while the communication is established.

Make Business calls from the Anywhere Feature

Your contacts will see the company information on their call display.

Call directly from your mobile

Dial your Anywhere number, enter the password of your VoiceMail then #.

Dial the destination number followed by #.

Example: 5141234567, 5894# 5144444742#

If you wish to program this function, enter only the first part:

YourAnywhereNumber , password #

Example: 5141234567 , 5894 #

You will only have to dial the destination number followed by #.

From another external phone

Dial your Anywhere number, enter the mobile number that is associated with your extension and #, enter the password of your VoiceMail then #. Dial the destination number and #.

Example: 5141234567, 5149876543# 5894# 5144444742#

If you wish to program this function, enter only the first part:

YourAnywhereNumber, mobile phone # password #

Example: 5141234567 , 5149876543 # 5894 #

You will only have to dial the destination number followed by #.

Programing Legend

#	Pound Key
,	Program a 3-second pause in the composition